## WoolMaste



RTU pH 11.5-12.0 1:4 - 64 Ceramic,Porcelain, Quarry Tile & Grout Floors & Surfaces

## **Rug and Fabric Preconditioner**

HydraMaster is pleased to provide you with a preconditioner/pre-spray specifically formulated to safely and effectively clean oriental rugs, wool rugs, carpet, and fabric; natural and cotton fiber rugs and fabric; and other investment textiles.



Available in: 1 Gallon; Case of 4 x 1 Gallon Part # 950-242 WoolMaster combines specialized encapsulation surfactants, detergents, and conditioning agents to specifically target the soils that rugs and fabrics are commonly exposed to.

- WoolMaster was formulated from the beginning for the specific purpose of effectively cleaning the most challenging rugs and fabrics, and meets and exceeds the safe standards for cleaning wool fibers and fabrics. WoolMaster is also formulated to match the versatility of the cleaning professional, working effectively at both "on-location" and "in-plant" cleaning set-ups.
- It can be applied like a typical prespray or used effectively in a rug washing pit.

## Directions:

Please read the full label directions before cleaning.

as a pre-treatment/prespray for tile and grout floors:

- 1. Always pre-test all cleaning solutions in an inconspicuous area for colorfastness prior to application.
- 2. For increased efficiency, apply HydraSolv with injection sprayer to take advantage of solution pressure and heat created by your high performance portable extractor or truckmount. You can also use a "pump-up" pressure sprayer, or electric or battery powered sprayer. Apply in even overlapping patterns.
- 3. For deep restorative cleaning, prespray with 1 part HydraSolv mixed with 4 parts hot water (32 ounces of solution with one gallon of water). For maintenance cleaning, mix HydraSolv 1 part solution to 16-32 parts water. For standard injection sprayer, mix one quart water with four quarts of Quake into 5 quart container.
- 4. Allow solution to dwell 2-5 minutes. Extra agitation with brushes compatible with tile and grout may be helpful.
- Extract the solution utilizing the RX-20 Rotary Extraction Tool with hard surface attachments, the RX15-H Rotary Hard Surface Tool, or any high pressure wand compatible with hard surface floors.
- 6. For faster drying, especially in humid environments, consider the use of an axial, centrifugal, or downdraft air mover after cleaning.





www.hydramaster.com | 800.426.1301 | 425.775.7272 sales@hydramaster.com