DAILY MAINTENANCE CDS 4.8
Check engine oil level
Empty recovery tank inlet filter
Inspect and clean garden hose screen
Visually inspect machine for loose wires, oil leaks, water leaks, etc
Inspect recovery tank stainless steel filter for clogging or damage; clean, repair or replace as needed
Inspect and clean the vacuum slot on the cleaning wand. Watch for sharp edges that may tear the carpet; remove any sharp edges as required
Lubricate blower with a HydraMaster-recommended spray lubricant (P/N 000-087-006) through lube port

INTERVAL IN HOURS CDS 4.8

| | | |